





elektronika systemów autogaz



67R - 01 4903
110R - 00 4904
10R - 03 6616




PC



STAG-4 plus

Wiring diagram.



Chose the proper type of sensor in software.

ATTENTION !!!
Description and connection diagram of UEGO sensor is located in the help section of controller configuration program.

ATTENTION !!!
Proper fuse needs to be placed into the socket.



Manufacturer:
AC Spółka Akcyjna
15-181 Białystok, ul. 42 Pułku Piechoty 50, Poland
tel. +48 85 7438148, fax +48 85 6538649
www.ac.com.pl, e-mail: autogaz@ac.com.pl

"04-106.95.00.1 z dn. 09.04.2013"